

## 24 Volt Submersible Well Pump Setup

## "Open Tank" Set Up

Pump is set up to run without batteries. Pump runs when the sun shines and pumps into an open tank which gravity feeds to your home.

## "Pressure Tank" Set Up

Pump is set up to run on batteries which are charged by solar modules. Pump runs when pressure drops in the pressure tank.

